



Zone	Add Insulation to Attic		Floor
	Uninsulated Attic	Exiting 3-4 Inches of Insulation	
1	R30 to R49	R25 to R30	R14
2	R30 to R60	R25 to R38	R13 to R19
3	R30 to R60	R25 to R38	R19 to R25
4	R38 to R60	R38	R25 to R30
5-8	R49 to R60	R38 to R49	R25 to R30

**Wall Insulation:** *Whenever exterior siding is removed* on an

**Uninsulated wood-frame wall:**

Drill holes in the sheathing and blow insulation into the empty wall cavity before installing the new siding, and  
 Zones 3-4: Add R5 insulative wall sheathing beneath the new siding  
 Zones 5-8: Add R5 to R6 insulative wall sheathing beneath the new siding.

**Insulated wood-frame wall:**

For Zones 4 to 8: Add R5 insulative sheathing before installing the new siding.